

USAGE

1 Gal Treats

160

Cubic Yards

1 Gal Treats

8,800

Square Feet
(at 6" deep)

EQUIPMENT REQUIRED



Water Truck



Grader



Smooth Wheel
Compactor



Sheepsfoot
Compactor (optional)

BINDTEK LIQUID APPLICATION STEPS

STEP 1. Rip Soil.



STEP 2. Moisten the Soil.



STEP 3. Mix Bindtek Liquid.



STEP 4. Apply Bindtek Liquid diluted mixture to soil.



STEP 5. Mix Bindtek Liquid thoroughly into soil.



STEP 6. Once soil can be formed without breaking, proper moisture has been achieved.



STEP 7. Compact thoroughly.

